

## OHV Piston Installation & Set Up

Wrist pin ID = .432" +/- check rules

Min recommended clearance .004"

- Finish hone the bore using a 400 grit stone with a light cross hatch and final finish using a few strokes with a fine plateau brush or ball hone.
- For best results, recommended end gap on compression (top) ring .010" minimum and scraper (2nd) .012" minimum. If you wish to utilize other gap clearances that you are comfortable with, then do so.
- Install with the arrow facing the flywheel.

For questions email us at [info@burrisracing.com](mailto:info@burrisracing.com) or call 714-375-3500